

How-to-Replace Your Groupe Central Alarm Battery


Removing the old battery:

1. Remove the **RED wire** from the **RED terminal**.
You may need to wiggle the terminal to remove it from the battery.
2. Remove the **BLACK wire** from the **BLACK terminal**.
In the unlikely event you find acid or corrosion on the battery terminal or battery connector, a replacement battery connector might be necessary.

RED & BLACK WIRES



RED & BLACK TERMINALS



Installing the new battery:

You could blow the fuse or destroy the alarm panel if the battery is connected backwards.

1. Connect the **RED wire** to the **RED terminal**.
2. Before connecting the **BLACK wire** to the battery. Ensure you have connected the **RED wire** to the **RED terminal**.
3. When you're **SURE** that **RED** is connected to **RED**, then you may connect the **BLACK wire** to the **BLACK terminal**.

NOTE: The "trouble" light can take 24 hours to clear from your keypad

Battery replacement instructions are similar even on different panels.

Avoid your siren from sounding by bypassing "tamper" before opening panel door.

When reconnecting to the new battery, the battery connectors should fit properly on the battery terminals. If loose, remove the connector from the battery and squeeze the connector (gently!) with a pair of pliers and reconnect. If you squeeze it too tightly, you will not be able to reconnect it to the battery.



Important note to avoid sending an alarm signal to your monitoring station:

Ensure your system is **OFFLINE** before changing the battery.

Call **1-877-403-8422**. Your **password** will be required for verification.

Our agents will be happy to schedule a service call or help you with a replacement battery:

Call: **1-877-403-8422** or **514-254-4420**

| Email: info@groupecentral.com